



Inspectron, Inc.
15120 Chippendale Ave.
Suite 104
Rosemount, MN 55068

Siding Installation Handout

PERMITS

Permits are required for installation of new siding, stucco or EFIS and repair or alteration of existing siding, stucco or EFIS that exceeds 100 square feet.

SUBMITTAL DOCUMENTS

- Completed permit application

LIST OF INSPECTIONS

SIDING

- Progress Inspection – After the siding is stripped off and house wrap and flashing around the windows and doors is in place. If threatening weather conditions exist, this inspection may be done on a single side of project containing at least one window.
- Final Inspection – When the job is complete and all penetrations have been caulked.

STUCCO OR EFIS

- Lathe Inspection – After lathe is installed and before application of coating.
- Final Inspection – When the job is complete and all penetrations have been caulked.

GENERAL CODE REQUIREMENTS

- Flashing must be installed over all exterior openings, continuously above all projecting wood trim and at wall and roof intersections.
- A kick out flashing is required at the lower portion of a sloped roof that ends within the plane of an intersecting wall to divert water from getting into the wall assembly.
- Nails, fasteners and siding must be installed according to the Manufacturer's specification.
- Building Code Table R703.4 specifies nail spacing for siding types. If you are unsure about spacing, contact Inspectron, Inc.

If you have questions, contact Inspectron, Inc. at 651-322-6626 or 800-322-6153 Monday through Friday between 8:00 am and 4:30 pm. We are happy to answer your project questions!

www.inspectroninc.com